



DIY Kit Instructions



Protecting Aussie farmers for 30 Years

Step 1

Remove all dust pads. Drill out pop rivets on both end caps and remove the carbon and indicator beads inside. Using compressed air, remove dust and dirt from the filter.



Step 2

Fill and pack with the activated carbon. Tap the filter firmly to ensure the carbon is tightly packed. Continue to tap up as carbon settles.



Step 3

Pop rivet the aluminium cap over the activated carbon. Place the purple indicator beads into the mesh cage at the opposite end of the carbon. Pop Rivet the perspex cap over the opening.



Step 4

Using compressed air and in a ventilated area, blow out any loose carbon and dust. Clean filter with cleaning agent or damp cloth.

Step 5


Remove foam seals from the filter, taking note of where seals are placed as some filters will have multiple seals.

Remove any residual adhesive on the filter.



Step 6

Apply seals to the correct position on the filter. Cut the corners with a sharp blade to create right angles. Glue joints together by gently prying two edges apart (any superglue or loctite will work).



Step 7

Replace foam dust pads, ensuring the pink/white media is closest to the carbon bed with the pink side facing down.



* IMPORTANT *

Please take this time to note the date of installation and place your window sticker in your cabin

Finished





Ultrasafe Products

1 Main Terrace Richmond SA 5033

Ph: (08) 8351 9222

www.ultrasafe.com.au